



## TOWEL WARMER (TP-207-1)



### Function:

This towel warmer is used for heating dry and damp towels, warming cosmetics, storing sterile instruments and accessories (sponges, brushes, napkins, etc.). The sterile environment will hold about two-dozen small hand towels (when rolled up) while maintaining a constant temperature of approximately 160°F - 176°F.

**NOTE:** This Towel Warmer is NOT a Sterilization Unit. It will ONLY maintain a sterile environment for ALREADY sterilized equipment.

**NOTE:** Please follow all your Local / State regulations regarding sterilization. Additional requirements may be necessary.

### Operating Instructions:

1. Plug the unit into a 110-120 Volt wall outlet and push the left power button to "ON" (the green light will illuminate).
2. Turn the heater on by pushing the right button (the red light will illuminate as well as the UV lamp inside the warmer).
3. Wait for 5 minutes, and then put the towels or tools on the stainless wire basket.